

Rigging Check List

Capri 14.2 Sloop

Derigging Check List

Capri 14.2 sloop

1. Safety check standing rigging.
2. Lower centerboard; attach bungee cord at transom.
3. Assemble tiller to rudder. Mount rudder to transom (tiller to be under traveler).
4. Pull mainsheet out of cam cleat on barney post; tie Figure 8 stopper knot in end of mainsheet; leave some slack in mainsheet.
5. Uncleat and loosen boom vang.
6. Remove and stow sail cover.
7. Remove and stow sail ties.
8. Remove main halyard shackle from outhaul and attach to head of mainsail. Do Not let go of halyard.
9. Use main halyard to hoist mainsail while guiding bolt rope into mast slot; cleat and coil main halyard.
10. Rig and cleat Cunningham; tighten boom vang and outhaul.
11. Remove jib from sail bag and stow bag.
12. Attach jib tack to bow fitting.
13. Attach jib hanks to forestay.
14. Attach jib halyard to head of jib.
15. Hoist jib; thread end of halyard through block (pulley) on halyard; cleat and coil jib halyard.
16. Lead jib sheets (one on each side of boat) outside shroud, through fairlead and cam cleat. Tie Figure 8 stopper in end of each jib sheet.

1. Un-cleat jib halyard; lower jib, keeping sail out of the water.
2. Remove jib halyard from head of jib; attach halyard shackle to line on mast; tie Figure 8 stopper knot in halyard and cleat halyard.
3. Unclip jib hanks and tack connection; release jib sheets.
4. Lay jib flat on dock and flake (fold); stow in sail bag.
5. Uncleat main halyard; lower mainsail so that boom stays inside the boat and sail does not get wet.
6. Remove main halyard from head of sail and attach to outhaul; use halyard to raise boom to horizontal position; cleat halyard.
7. Pull slack out of mainsheet; lead mainsheet through cam cleat on barney post; tie Figure 8 stopper knot.
8. Flake (fold) mainsail onto boom; secure with sail ties fastened with reef (square) knots.
9. Put on sail cover.
10. Coil mainsheet and loop over boom.
11. Lift rudder out of gudgeons; disassemble tiller from rudder.
12. Unclip centerboard bungee cord from transom; raise and secure centerboard.
13. Put centerboard bungee over boom and clip to boom vang.
14. Put centerboard tether line over boom.
15. Rinse rudder with fresh water.
16. Clean boat with brush, soap and water.
17. Flemish docking lines.